



Change language:

BMW TIS - 11 13 000 Removing and installing, sealing or replacing oil sump (M54)

11 13 000	Removing and installing, sealing or replacing oil sump (M54)
	Necessary preliminary tasks: <ul style="list-style-type: none">· Remove intake filter housing· Remove guide tube for oil dipstick· Lowering front axle support· Drain off engine oil· Disconnect plug connection to oil level sensor.
	On vehicles with automatic transmission: Detach oil lines from automatic transmission and from oil pan.
 <p>50 11 195 U</p>	Unfasten oil pan screws at transmission and engine ends. Lower and remove oil pan.
	Installation: Sealing faces clean and free of



seal debris.

Apply approx. 3 mm wide, 2 mm high coat of Drei Bond 1209 sealing agent (refer to BMW Parts Service) to the area around seams.

Installation:

1. Replace seal.
2. Install oil sump.
3. Insert all screws on transmission end,
4. without preload at this stage.
5. Tighten down screws on engine end.
6. Tighten screws on transmission end.

No posts yet.

Please [register](#) before posting.

Username	<input type="text"/>
Password	<input type="password"/>
Title	<input type="text"/>